

# 350Z Plug and Play Module external connectors description

External Connector J4 (WBO)			
WBO 12V(4)	4	1	WBO IP (1)
WBO Rcal (5)	5	2	WBO VGND (2)
WBO VS (6)	6	3	WBO Heater(3)

External Connector J5 (spare io)			
Aux 4	7	1	Power GND
Aux 3	8	2	12V+
Flex Fuel	9	3	
Analog 6	10	4	
Analog 5	11	5	Sensor GND
SW3	12	6	5V